



Deze download wordt u gratis aangeboden door Pick-upnaalden.nl

Web : www.pickupnaalden.com
Email : info@pick-upnaalden.nl
Facebook : www.facebook.com/pickupnaalden
Twitter : twitter.com/Pickupnaalden
Google+ : https://plus.google.com/+FCaris_pickupnaalden

Service Manual

 **PIONEER®**
The Art of Entertainment

STEREO TURNTABLE

PL-Z94 ZEBM

PL-Z570 ZEBM

PL-Z470 ZEBM

- Refer to the service manual ARP1478, PL-Z91/ZEBM type.
- This manual is applicable to the PL-Z94/ZEBM, PL-Z570/ZEBM and PL-Z470/ZEBM types.
- These products are components of systems. As to the system composition, refer to the applicable system manuals.

NOTES :

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

The PL-Z94/ZEBM, PL-Z570/ZEBM and PL-Z470/ZEBM types are the same as the PL-Z91/ZEBM type with the exception of the following sections.

Mark	Symbol & Description	Part No.				Remarks
		PL-Z91/ZEBM	PL-Z94/ZEBM	PL-Z570/ZEBM	PL-Z470/ZEBM	
	Sub-panel assembly	Non supply	Non supply	Non supply	Non supply	
	Name plate			Non supply	Non supply	
	Speed button	PAC1226	PAC1226	PAC1436	PAC1436	
	EV button	PAC1227	PAC1227	PAC1437	PAC1437	
	S/S button	PAC1228		PAC1423		
	Cut button		PAC1467		PAC1469	
	Front name plate	PAM1156	PAM1484	Non supply	Non supply	
	Front name plate assembly			PEA1138	PEA1137	
	Insulator	PEB1061	PEB1061	PEB1155	PEB1155	
	Insulator assembly			PXA1370	PXA1370	
	Arm assembly	PPD1016	PPD1027	PPD1027	PPD1027	
	Cut rod		Non supply		Non supply	
	Size rod	Non supply		Non supply		
	S/S rod	Non supply		Non supply		
	Protector(R)	PHA1045	PHA1045	PHA1082	PHA1082	
	Protector(L)	PHA1046	PHA1046	PHA1083	PHA1083	
	Turn table	PNR1025	PNR1037	PNR1037	PNR1037	
	Button stopper F	PBK1038		PBK1038		
	Button stopper R		PBK1037		PBK1037	
	Packing case	PHG1163	PHG1599	PHG1604	PHG1603	
	Panel	PNW1294	PNW1292	PNW1493	PNW1734	
	Start lever	Non supply		Non supply		
	PU plate assembly	PXA1109		PXA1109		
	PU plate(B) assembly		PXA1114		PXA1114	

Note: The PU plate(B) assembly (PXA1114) is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

The Sub-panel assembly of PL-Z570/ZEBM type is the same as that of PL-Z91/ZEBM type.

The Sub-panel assemblies of PL-Z94/ZEBM and PL-Z470/ZEBM types are the same as the sub-panel assembly of PL-Z91/ZEBM with the exception of the following sections.

Mark	Symbol & Description	Part No.			Remarks
		PL-Z91/ZEBM	PL-Z94/ZEBM	PL-Z470/ZEBM	
	Select lever spring	PBH1053			
	Reset plate spring	PBH1054			
	Select lever	PBH1096			
	Index cam	PNW1296			
	Reset plate	PNW1312			
	Selector	PNW1313			
	Drive plate assembly	PXA1110	PXA1112	PXA1112	

Note: The Drive plate assembly (PXA1112) is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.